

2000-2002 CHEVROLET TAHOE/YUKON



Year: 2000-02 Make: Chevrolet
Year: 2000-02 Make: GMC

Model: Tahoe
Model: Yukon

IN-DASH APPLICATION:

Dash Type: DIN+1/2

Kit: GM1485/GM1486

Harness: GMO2

Antenna Adapter: MDA-1

Factory Amplifier: Located behind glovebox and behind the driver's rear quarter panel

FRONT SPEAKERS:

Door: 1-5/16" Tweeter mounted to back of factory door panel

Door: 7" 4-Hole Pin Cushion speaker built into a factory adapter

WHEN INSTALLING AN AFTERMARKET 5 ¼ OR 6 ½" SPEAKER, A SPEAKER ADAPTER IS REQUIRED. WE RECOMMEND THE USE OF A SCOSCHE SAGMT95 SPEAKER ADAPTER.

REAR SPEAKERS:

Door: Standard 6 ½" 4-Hole Pin Cushion speaker mounted directly in steel

Subwoofer: 8" subwoofer located in rear driver's side panel

WIRE COLOR CODES:

Note: plug behind radio is standard colors on GMO2 using FAI. At amplifier color codes are as follows.

+12V Constant	=	Orange
+12V Accessory Switched	=	Green (Only when factory radio is plugged in)
-12V Chassis Ground	=	Black
+12V Illumination	=	Gray
+12V Dimmer	=	Gray
LF+	=	Tan
LF-	=	Gray
RF+	=	Lt Green
RF-	=	Dk Green
LR+	=	Brown
LR-	=	Yellow
RR+	=	Dk Blue
RR-	=	Lt Blue
Sub+	=	Green/Black
Sub-	=	Blue/White

2001 Chevrolet Tahoe/Yukon

PRELIMINARY: Disconnect the negative battery cable.

ANTENNA: Front passenger side fender.

RADIO REMOVAL AND IN-DASH INSTALLATION:

Note: The factory radio provision is for a DIN and half sized radio. Recommended kit GM1583.

1. Turn Ignition on and shift vehicle into lowest position.
2. Carefully pull trim panel towards you, and Unsnap.

FRONT DOOR SPEAKER INSTALLATION:

Note: The factory speaker provision is for a 6 ½" 3-hole Round mounted speaker.

1. Use panel removal tool to remove plastic triangle.
2. Use panel removal tool to remove plastic trim bezel around door opener handle.
3. Use panel removal tool and remove window control panel, Disconnect and remove. Extract (1) 9/32" screw from behind.
4. Extract (1) 9/32" from behind door handle.
5. Use panel removal tool and remove door lock and unlock indicator.
6. Pull upwards on door panel, Disconnect and remove all connectors.
7. Push down on top finger tad of speaker and remove.

REAR DOOR SPEAKER INSTALLATION:

Note: The factory speaker provision is for a 6 ½" 4-Hole Standard Mounted speaker.

1. Extract (1) 9/32" screw from bottom corner of door panel.
2. Extract (1) 9/32" from upper door handle.
3. Using a small flat screw driver, remove plastic bexel from door opener handle.
4. Pull upwards on door panel, Disconnect and remove.
5. Extract (4) T-15 torx screws from speaker, Diconnect and remove.

REAR SIDE PANEL SPEAKER INSTALLATION:

Note: The factory speaker provision is for a 3 ½" 4-Hole Standard Mounted speaker.

1. Remove top center panel with panel removal tool.
2. Remove plastic slide panel with panel removal tool.
3. Cut wire tie and extract speaker, disconnect and remove.

REAR SUB WOOFER SPEAKER INSTALLATION:

Note: The factory speaker provision is for a 8" Standard Mounted speaker.

1. Remove 3rd rear seat.
2. Remove driver rear side panel.

