




Make: Chevrolet
 Model: Tahoe/Suburban
 Year: 2007-13



Scosche Pro App

STANDARD/ OPTIONAL

- AM/FM in-dash CD Player
- Ipod Capable
- Satellite Radio Capable
- Steering Wheel Controls
- BOSE Audio System

SCOSCHE®

SPEAKER NOTES

Front Speakers

Upper Door:	1"
Lower Door:	6 1/2"
Speaker Adapter:	SAGMHR634
Speaker Harness:	SHGM03B
Speaker Assembly:	(1) 9/32 Screws

Dimensions:	Tweeter	Door
	L: 1.00"	L: 6.50"
	W: 1.00"	W: 6.50"
	D: 1.00"	D: 2.75"

Rear Speakers

Lower Door:	5 1/2"
Rear Pillar:	2"
Speaker Adapter:	N/A
Speaker Harness:	SHGM03B
Speaker Assembly:	(1) 9/32 Screws

Dimensions:	Door	Pillar
	L: 5.50"	L: 2.00"
	W: 5.50"	W: 2.00"
	D: 4.00"	D: 1.00"

APPLICATIONS

Dash Type:	Double Din
Aftermarket Type:	Single/Double Din
Aftermarket Kit:	GM1598AB
Harness:	GM22SR/GM21SR
Antenna Adapter:	CRAB/CRARB
Amplifier Location:	Under Center Console

Auxiliary Input:	Glove Box
------------------	-----------

FACTORY COLOR CODES

(+)12v Battery:	Red/White
(+)12v Accessory:	Data
(-) 12v Ground:	Black
(+)12v Amp Turn On:	Data
Left Front Speaker (+):	Tan
Left Front Speaker (-):	Gray
Right Front Speaker (+):	Lt. Green
Right Front Speaker (-):	Drk. Green
Left Rear Speaker (+):	Brown
Left Rear Speaker (-):	Yellow
Right Rear Speaker (+):	Drk. Blue
Right Rear Speaker (-):	Lt. Blue

PRELIMINARY:

Disconnect the negative battery cable.

Make: Chevrolet

Model: Tahoe/Suburban

Year: 2007-13



Scosche Pro App



RADIO REMOVAL



1. Using a PRT unsnap the dash bezel surrounding the factory radio.
2. Extract (8) 9/32 bolts securing the factory radio.
3. Lift away disconnect and remove.

FRONT DOOR TWEETERS



1. Extract (2) 10mm bolts securing the A pillar handle.
2. Using a PRT unsnap the top of the A pillar. Lift away, disconnect and remove.
3. Tweeter is secured to A pillar by plastic snaps.

FRONT DOOR SPEAKERS



1. Remove (1) 10mm hex bolt located in the door release cup.
2. Located in the middle of the door panel behind the door handle there is a small panel hiding (2) 10mm hex bolts. Using a pick tool remove the panel and extract (2) hex bolts.
3. Unlock the door to make sure the door lock pin is resting in its highest position. Release tab located at the bottom and lift up on the door pin to remove.
4. Using a PRT unsnap the parameter of the door panel. Lift away disconnect and remove.
5. Extract (1) 9/32 securing the factory speaker, lift away disconnect and remove

REAR DOOR SPEAKERS



1. Remove (1) 10mm hex bolt located in the door release cup.
2. Located in the middle of the door panel behind the door handle there is a little panel hiding (1) 10mm hex bolts. Using a pick tool remove the panel and extract the (1) hex bolt.
3. Unlock the door to make sure the door lock pin is resting in its highest position. Release tab located at the bottom and lift up on the door pin to remove.
4. Using a PRT unsnap the parameter of the door panel. Lift away disconnect and remove.
5. Extract (1) 9/32 securing the factory speaker, lift away disconnect and remove.

PRELIMINARY:

Disconnect the negative battery cable.


Make: Chevrolet

Model: Tahoe/Suburban

Year: 2007-13



Scosche Pro App



AMPLIFIER

PHOTO NOT AVAILABLE

Location: Under Center Console
Disassembly: Extract (3) 10mm. Bolts

REAR PILLAR TWEETER



1. Using a PRT remove the rear panel running across the headliner from one pillar to the other.
2. Using a pick tool remove the small oval panel covering the (1) Phillips screw.
3. Extract (1) Phillips screw from the rear panel. Using a PRT unsnap pillar, lift away disconnect and remove.
4. Remove (1) Philips securing the factory tweeter to the pillar panel.

AUX/USB



REAR ENTERTAINMENT

