

STEREO REPLACEMENT & STEERING WHEEL CONTROL INTERFACE FOR SELECT 2011-15 VOLKSWAGEN **STEREOS**

This LPVW25 allows you to replace your factory OEM stereo while retaining factory steering wheel controls, OEM phone buttons and Fender amplifier control (if vehicle is equipped)





DESIGNED & ENGINEERED IN U.K. CUSTOM MANUFACTURED IN CHINA

VOLKSWAGEN:

2012-15 BEETLE 2013-UP JETTA GLI **2011-15 PASSAT**

For vehicles with Quadlock (40 Pin) Connector

FEATURES

RETAINS:

- -Retains Steering wheel controls (if equipped)
- -Retains Fender amplifier control
- -Retains OEM phone buttons (if equipped)

This LPVW25 instruction manual is based on carefully documented data and research. Scosche Industries Inc. cannot be held responsible for discrepancies/inconsistencies that may occur due to the vehicle manufacturing changes or options, or damages that may occur in the vehicle during the installation of components while using this manual.

WIRING COLOR CODES

White= Left Front Positive (LF+) White/Black= Left Front Negative (LF-) Green= Left Rear Positive (LR+) Green/Black= Left Rear Negative (LR-) Black= Chassis Ground +12V Constant Power Yellow= Rad= +12V Accessory Blue= +12V Power Antenna

(Remote Out)

Gray= Gray/Black= Violet= Violet/Black= Orange= Right Front Positive (RF+) Right Front Negative (RF-) Right Rear Positive (RR+) Right Rear Negative (RR-) Illumination


Purple/White = Reverse signal

Green = Park brake **Pink** = Speed pulse

Blue/White = Amp Remote

NOTE: The **RED** accessory output wire from the *LPVW25* interface is rated at 10A Max output for most aftermarket head units. **We do NOT** recommend connecting additional +12A switched accessories to this output source as that may cause damage to the *LPVW25* module itself. If 10A output is not sufficient, then a relay is needed. **(Relay not included)**

STEERING WHEEL WIRING CODES SWC DIAGRAM



- 1. Prepare SWC steering wheel connector harness by using the chart below
- 2. Connect the harness to the interface module.
- 3. For Alpine, Clarion, JVC, Panasonic and Sony car stereos, connect the 3.5mm male steering plug into the steering wheel input jack at the back of the stereo.
- For Kenwood and newer JVC stereos, connect the **BROWN** wire from the steering wheel harness
 to the "Remote in" wire at the back of the stereo


STEREO BRAND	CONFIGURATION	CONNECTION TO STEREO
ALIPNE	Cut Green Loop	3.5mm
CLARION	Cut Violet Loop	3.5mm
JVC	Cut Green & Violet Loop	3.5mm or Brown (Key1)
KENWOOD	Cut Orange & Green	Brown (Key 1)
PANASONIC	Cut Orange	Brown (Key 1)
PIONEER / SONY	Do Not Cut Loops	3.5mm
OTHER BRANDS	Call Tech Support	Brown, Gray, Black




If you have any questions or need technical assistance with the installation, or the most current application please call or visit us on the web at:

(800) 363-4490 x1 | www.scosche.com/contact


SWC WIRING HARNESS






Pioneer / Sony Sample 3


NOTE: Do NOT cut or remove wires



STEERING WHEEL CONTROLS

NB: Enter the Amp Control Menu by holding OK or Voice for 5 seconds. Use Vol +/- to change values, and Disk +/- (or Track +/-) to change items. To exit the menu, press and hold OK or Voice for 2 seconds. Note that the SWC will not operate the radio whilst in the Amp Control Menu.





- 1. Volume +
- 2. Volume -
- 3. Track Down
- 4. Track Up
- 5. Pick Up (Short Press) Hang Up (Long Press)
- 6. Mute
- 7. Disk Up (In Audio Mode)
- 8. Disk Down (In Audio Mode)

Detach this page for customer use

LPVW25 WIRING DIAGRAM



STEREO BRAND	CONFIGURATI	CONNECTION TO STEREO
ALPINE	Cut Green Loop	3.5mm
CLARION	Cut Violet Loop	3.5mm
JVC	Cut Green & Violet Loop	3.5mm or Brown (Key 1)
KENWOOD	Cut Orange & Green	Brown (Key 1)
PANASONIC	Cut Orange	Brown (Key 1)
PIONEER / SONY	Do Not Cut Loops	3.5mm
OTHER BRANDS	Call Tech Support	Brown, Gray, Black

