

2010-11 Ford Taurus

ABOUT THE VEHICLE



Make: Ford
 Model: Taurus
 Year: 2010-11

STANDARD/ OPTIONAL

- AM/FM/SAT/Multi CD Player
- Bluetooth (SYNC)
- USB/iPod/3.5mm Aux/mp3
- 12 Speaker Premium SONY system
- Steering Wheel Controls
- SYNC w/Voice control capability

SCOSCHE®

SPEAKER NOTES

Front Speakers

Center Dash:	3 1/2"
Pillar:	1"
Lower Door:	6x8"
Speaker Adapter:	SA68
Speaker Harness:	TBA
Speaker Assembly:	(2) 8mm/Clips/(4) 1/4"

Dimensions:

Center	A Pillar	Front Door
L: 3.58"	L: 1.56"	L: 5.24"
W: 3.58"	W: 1.56"	W: 7.24"
D: 1.68"	D: 0.78"	D: 2.88"

Rear Speakers

Lower Door:	6x8"
Rear Deck:	3 1/2" and 6x9" (Premium only)
Speaker Adapter:	SA68
Speaker Harness:	TBA
Speaker Assembly:	1/4" / 8mm Hex screws

Dimensions:

Back Door	Rear Deck	Reck Deck
6x8"	3 1/2"	6x9"
L: 6.24"	L: 3.49"	L: 9.17"
W: 6.24"	W: 3.49"	W: 6.25"
D: 2.51"	D: 1.78"	D: 4.69"

APPLICATIONS

Dash Type:	New Integrated Dash
Aftermarket Type:	Single/Double Din
Aftermarket Kit:	FD1447B
Harness:	FDSR
Antenna Adapter:	CRAB/CRARB
Auxiliary/USB Input:	Inside Center Console
Amplifier Location:	Trunk (Left side)

FACTORY COLOR CODES

(+)12v Battery:	White/Red
(+)12v Accessory:	Data
(-) 12v Ground:	Black/Blue
(+)12v Amp Turn On:	Data
Left Front Speaker (+):	White
Left Front Speaker (-):	White/Brown
Right Front Speaker (+):	White/Purple
Right Front Speaker (-):	White/Orange
Left Rear Speaker (+):	White/Green
Left Rear Speaker (-):	Brown/Yellow
Right Rear Speaker (+):	Brown/White
Right Rear Speaker (-):	Brown/Blue

2010-11 Ford Taurus

VEHICLE DISASSEMBLY

PRELIMINARY:

Disconnect the negative battery cable.

Make: Ford

Model: Taurus

Year: 2010-11

RADIO



1. With Panel Removal Tool, unclip shifters leather boot pushing down on the chrome ring then extract (2) T-20 Torx Screws revealed and remove shifter.
2. With Panel Removal Tool, unclip upper sides center console's panels, unplug and remove.
3. Extract (4) 8mm screws securing the far rear panel/cup holder on the center console, unplug and remove.
4. Extract (4) 8mm screws securing shifter/cup holder panel, unplug and remove.
5. Extract (4) 8mm screws securing 12V Panel under Radio/AC Panel, unplug and remove.
6. With Panel Removal Tool, unclip top portion of the Panel underneath the steering wheel column.
7. Extract (1) 8mm screw securing panel to the left of the steering wheel, then with panel removal tool, unclip, unplug and remove.
8. With Panel Removal Tool, unclip panel to the right of the steering wheel, unplug and remove.
9. With Panel Removal Tool, unclip gauge panel and remove.
10. With Panel Removal Tool, unclip panel above glove compartment.
11. Extract (10) 8mm screws securing Radio/AC Panel, with panel removal tool, unclip, unplug and remove.
12. Extract (4) 8mm screws securing Radio Display, unplug and remove.
13. Extract (4) 8mm screws securing Radio, unplug and remove.

AUX/3.5mm



SYNC



ANTENNA



2010-11 Ford Taurus

VEHICLE DISASSEMBLY

PRELIMINARY:

Disconnect the negative battery cable.

Make: Ford

Model: Taurus

Year: 2010-11

CENTER DASH SPEAKER



1. With Panel Removal Tool, unclip Speaker Grill.
2. Extract (2) 8mm screws securing Speaker, unplug and remove.

PILLAR TWEETERS



1. Pull down on the rubber seal running along the Pillar.
2. With Panel Removal Tool, unclip Pillar Panel, unplug and remove.
3. With a flat head screw driver, unclip Tweeter and remove.

FRONT DOOR SPEAKERS



1. With Panel Removal Tool, unclip side mirror panel, unplug and remove.
2. With Panel Removal Tool, unclip window controls panel, unplug, remove and extract (1) 10mm screw.
3. With Pick Tool, unclip panel inside door handle and extract (1) 10mm screw.
4. With Panel Removal Tool, unclip wood trim panel on the top portion of the door panel and extract (1) Phillips Head Screw and (1) 8mm screw.
5. Extract (3) Phillips Head Screws on the lower outer perimeter of the door panel.
6. With Panel Removal Tool, unclip door panel, unplug and remove.
7. Extract (4) 1/4" screws securing Speaker, unplug and remove.

REAR DOOR SPEAKERS



1. With Panel Removal Tool, unclip Window Control Panel, unplug, remove and extract (1) 10mm screw.
2. With Pick Tool, unclip panel inside door handle and extract (1) 10mm screw.
3. With Panel Removal Tool, unclip wood trim panel on the top portion of the door panel and extract (1) Phillips Head Screw and (1) 8mm screw.
4. Extract (2) Phillips Head Screws on the lower outer perimeter of the door panel.
5. With Panel Removal Tool, unclip door panel, unplug and remove.
6. Extract (4) 1/4" screws securing Speaker, unplug and remove.

2010-11 Ford Taurus

VEHICLE DISASSEMBLY

PRELIMINARY:

Disconnect the negative battery cable.

Make: Ford

Model: Taurus

Year: 2010-11

REAR DECK CENTER SPEAKER



1. Twist the left and right side seat release located on the front bottom portion (above floor panel) of the back seat and pull seat up.
2. Push seat back and pull up to release.
3. With Panel Removal Tool, unclip the bottom portion of the back seat's side cushion panels and push top portion down to release.
4. Remove rear doors rubber seals then extract (1) 7mm screw securing rear deck's top side panels and with Panel Removal Tool, unclip and remove.
5. With Panel Removal Tool, unclip (3) plastic screw tabs securing the rear deck panel, un-hook seatbelts and remove.
6. Extract (2) 1/4" screws securing rear deck center speaker, unplug and remove.

REAR DECK SUBWOOFERS



1. Twist the left and right side seat release located on the front bottom portion (above floor panel) of the back seat and pull seat up.
2. Push seat back and pull up to release.
3. With Panel Removal Tool, unclip the bottom portion of the back seat's side cushion panels and push top portion down to release.
4. Remove rear doors rubber seals then extract (1) 7mm screw securing rear deck's top side panels and with Panel Removal Tool, unclip and remove.
5. With Panel Removal Tool, unclip (3) plastic screw tabs securing the rear deck panel, un-hook seatbelts and remove.
6. Extract (4) 1/4" screws securing 6X9" subwoofers, unplug and remove.

SPEAKERS AMPLIFIER



1. With Panel Removal Tool, unclip trunks running board and remove.
2. With Panel Removal Tool, unclip (3) plastic screw tabs and unscrew (3) plastic screws securing left side panel.
3. Begin removing the side panel, unplug trunk light and fold panel towards the front of the trunk.
4. Unplug Speakers Amplifier and remove by extracting (4) Phillips Head Screws.

SUBWOOFERS AMPLIFIER



1. With Panel Removal Tool, unclip trunks running board and remove.
2. With Panel Removal Tool, unclip (3) plastic screw tabs and unscrew (3) plastic screws securing left side panel.
3. Begin removing the side panel, unplug trunk light and fold panel towards the front of the trunk.
4. Unplug Subwoofers Amplifier and remove by extracting (4) 7mm Screws.