

# Harley Davidson

## ABOUT THE VEHICLE



Make: Harley Davidson  
Model: Street Glide/FLHX/FLHT  
Year: 2006-UP/96-UP



google play

### STANDARD/OPTIONAL

- AM/FM/CD
- 2 Speaker System/Tour Pack w/4 Speakers
- 3.5mm AUX
- Handle Bar Controls

## SCOSCHE®

### SPEAKER NOTES

#### Front Speakers:

Upper Fairing Speaker:	5 1/4"
Upper Fairing Tweeter:	TBA
Speaker Adapter:	SAHD656
Speaker Harness:	N/A
Speaker Assembly:	(4) T-25 Screws Securing The Speaker

#### Dimensions:

Tweeter	Speaker
L: 0.00"	L: 5.25"
W: 0.00"	W: 5.25"
D: 0.00"	D: 2.00"

#### Rear Speakers: (FACTORY OPTION)

Rear Fender Bags:	5 x 7"
Speaker Adapter:	N/A
Speaker Harness:	N/A
Speaker Assembly:	(4) T-25 Screws Securing The Speaker

#### Dimensions:

Rear Bags
L: 7.00"
W: 5.00"
D: 2.75"

### APPLICATIONS

Dash Type:	Single DIN
Aftermarket Type:	Single DIN

#### Aftermarket Kits:

Aftermarket Kit:	HD7000B
------------------	---------

#### Harness/Interface/Adapters:

Radio Harness:	Included with kit
Antenna Adapter:	Not Required
Blue Fusion/Bluetooth:	BT1000/BT1200
AUX / iPod Interface:	FMMOD02

#### Other:

Auxiliary Input:	On Radio
USB Input:	N/A
Amplifier Location:	N/A

#### FACTORY COLOR CODES

12v Battery (+):	Red/Orange
12v Accessory (+):	Orange/Beige
12v Ground (-):	Black/Green
12v Amp Turn On (+):	N/A
Illumination:	N/A
Left Front Speaker (+):	White/Orange
Left Front Speaker (-):	L. Green/White
Right Front Speaker (+):	Grey/Red
Right Front Speaker (-):	L. Green/Black
Left Rear Speaker (+):	N/A
Left Rear Speaker (-):	N/A
Right Rear Speaker (+):	N/A
Right Rear Speaker (-):	N/A

### PRELIMINARY:

Disconnect the negative battery cable.

Make: Harley Davidson

Model: Street Glide/FLHX/FLHT

Year: 2006-UP/96-UP



## RADIO REMOVAL

- 1) Drape a protective cloth over the front fender.
- 2) Extract (3) T-27 Torx bolts from bottom edge of windshield.
- 3) Carefully lift away windshield, store in a safe location and replace the middle Torx bolt for support during the remaining removal steps.
- 4) Extract (2) T-27 Torx bolts from outer side of the fairing (under mirrors)
- 5) Extract (2) T-27 Torx bolts from inside the fork tubes (facing forward)
- 6) While supporting the outer fairing, remove the middle windshield bolt, lift away and unplug headlight to remove fairing shell. Store fairing in a safe place until re-assembling.
- 7) Unbolt and remove inner fairing support brackets from each side (3/16 HEX" & T-25 Torx screws) Note the Torx screw is also a shared speaker screw.
- 8) Extract (2) ¼" 6 MM Hex bolts from each side of the radio housing.
- 9) Carefully back the radio out of the fairing, unplug wiring connectors, antenna and remove the radio.



## FRONT SPEAKERS



- 1) Follow the same outer fairing removal steps to access or replace the radio to access the Factory speakers.
- 2) Use a T-25 Torx driver and extract (4) screws securing each speaker, unplug and remove speakers & spacers.

## REAR SPEAKERS

