

2010-11 Kia Forte



SCOSCHE®

SPEAKER NOTES

Front Speakers

| | |
|-------------------|------------------------------|
| Door Tweeter: | 1" |
| Lower Door: | 6 1/2" |
| Speaker Adapter: | TBA |
| Speaker Harness: | SHHY01B |
| Speaker Assembly: | Tweeter: Clipped on. |
| Lower door: | (4) Rivets securing Speaker. |

| | | |
|-------------|----------|------------|
| Dimensions: | Tweeter | Lower Door |
| | L: 0.000 | L: 0.000 |
| | W: 0.000 | W: 0.000 |
| | D: 0.000 | D: 0.000 |

Rear Speakers

| | |
|-------------------|-------------------------|
| Lower Door: | 6 1/2" |
| Rear Side Panel: | 6 1/2" |
| Speaker Adapter: | TBA |
| Speaker Harness: | SHUI01B |
| Speaker Assembly: | (4) Rivets/(4) Phillips |
| Head Screws | securing Speaker. |

| | |
|-------------|----------|
| Dimensions: | 6 1/2" |
| | L: 6.257 |
| | W: 6.257 |
| | D: 2.695 |

ABOUT THE VEHICLE



Make: Kia
 Model: Forte Koup/SX
 Year: 2010-11

STANDARD/ OPTIONAL

- AM/FM/MP3 in-dash CD Player
- ipod/3.5mm Aux/mp3 input
- Satellite Radio Capable
- Steering Wheel Controls
- 6 Speaker System
- Bluetooth

APPLICATIONS

| | |
|---------------------|-------------------|
| Dash Type: | Custom Dash |
| Aftermarket Type: | Single/Double Din |
| Aftermarket Kit: | KA2410B/KA2410SB |
| Harness: | HY10B |
| Antenna Adapter: | KAAB |
| Amplifier Location: | N/A |
| Auxiliary Input: | Below Radio |

FACTORY COLOR CODES

| | |
|--------------------------|--------|
| (+)12v Battery: | Black |
| (+)12v Accessory: | Yellow |
| (-) 12v Ground: | Red |
| (+)12v Amp Turn On: | Gray |
| Left Front Speaker (+): | Black |
| Left Front Speaker (-): | White |
| Right Front Speaker (+): | Black |
| Right Front Speaker (-): | Yellow |
| Left Rear Speaker (+): | Blue |
| Left Rear Speaker (-): | Red |
| Right Rear Speaker (+): | Blue |
| Right Rear Speaker (-): | Red |

PRELIMINARY:

Disconnect the negative battery cable.

Make: Kia

Model: Forte Koup/SX

Year: 2010-11

RADIO REMOVAL



1. With Panel Removal Tool, unclip air vents on the left and right side of the Radio.
Note: it's possible that the air vent trim bezel will pop out and not the vent itself. If that occurs, make sure to remove the vent after you have removed the bezel.
2. Extract (4) Phillips Head Screws Securing Radio, (2) on the left and (2) on the right.
3. With Panel Removal Tool, unclip Radio, unplug and remove.
4. Remove A/C control panel from Radio Panel by extracting (4) Phillips Head Screws from behind.
5. Remove Hazard Switch from Radio Panel by extracting (4) Phillips Head Screws from behind.

REAR DOOR SPEAKERS



1. With Panel Removal Tool, unclip side panel above door panel.
2. With small flat head screw driver, open screw cover inside door handle and extract (1) Phillips Head Screw.
3. With small flat head screw driver, open screw cover right below door grip and window switch control panel and extract (1) Phillips Head Screw.
4. With Pick Tool, unclip screw cover on top/side section of door panel and extract (1) Phillips Head Screw.
5. With Panel removal tool, unclip Door Panel, unplug and remove.
6. With a dremel or drill bit, remove (4) rivets securing Speaker, unplug and remove.

FRONT DOOR SPEAKERS



1. With Panel removal Tool, unclip side mirror panel/tweeter panel, unplug and remove.
2. With small flat head screw driver, open screw cover inside door handle and extract (1) Phillips Head Screw.
3. With small flat head screw driver, open screw cover right below door grip and window switch control panel and extract (1) Phillips Head Screw.
4. With Pick Tool, unclip screw cover on top/side section of door panel and extract (1) Phillips Head Screw.
5. With Panel Removal tool, unclip Door Panel, unplug and remove.
6. With a dremel or drill bit, remove (4) rivets securing Speaker, unplug and remove.

REAR SIDE PANEL SPEAKERS



1. With Panel Removal Tool, unclip running board and remove door seal.
2. Fold back seat and with Panel Removal Tool, remove (2) plastic screws securing side panel.
3. With panel removal Tool, unclip side panel and remove.
4. Extract (4) Phillips Head Screws Securing Speaker, unplug and remove.

2010-11 Kia Forte

VEHICLE DISASSEMBLY

PRELIMINARY:

Disconnect the negative battery cable.

Make: Kia

Model: Forte Koup/SX

Year: 2010-11

KOUP (2) DOOR



SX (4) DOOR



ANTENNA/AUX/iPOD/USB



STEERING WHEEL CONTROLS/BLUETOOTH

