

TUNERS / CASSETTE / DISC PLAYERS						RADIO EQ STACK
	MINI	STAN	DIN	ISO DIN	SINGLE DBL DIN	
CHASSIS H	1 $\frac{1}{2}$ "-2	2	2	2	3 $\frac{7}{8}$	3
CHASSIS W	7 $\frac{1}{8}$	7 $\frac{1}{8}$	7 $\frac{1}{8}$	7	7 $\frac{1}{8}$	7 $\frac{1}{8}$
CHASSIS D	4 $\frac{3}{4}$ "-5 $\frac{1}{2}$	5 $\frac{7}{8}$ -6 $\frac{11}{16}$	5 $\frac{7}{8}$ -6 $\frac{11}{16}$	5 $\frac{7}{8}$ -6 $\frac{11}{16}$	5 $\frac{7}{8}$ -6 $\frac{11}{16}$	5 $\frac{7}{8}$ -6 $\frac{11}{16}$
NOSE H	1 $\frac{5}{8}$ "-1 $\frac{3}{4}$	1 $\frac{5}{8}$ "-1 $\frac{3}{4}$	2 $\frac{3}{8}$	1 $\frac{3}{4}$	3 $\frac{3}{4}$ "-4	
NOSE W	4 $\frac{1}{8}$ "-4 $\frac{3}{16}$	4 $\frac{1}{8}$ "-4 $\frac{3}{16}$	7 $\frac{1}{2}$	6 $\frac{11}{16}$	6 $\frac{11}{16}$ "-7 $\frac{1}{4}$	
SHAFT SP.	5 $\frac{1}{2}$ "-5 $\frac{3}{4}$	5 $\frac{1}{2}$ "-6				
IN DASH APPLICATION NOTES						
	K ^S	K ^S	K ^S	K ^S	K ⁴	K ^S


APPLICATION KIT MODEL:	FD1300/FCJ1275A
HARNESS ADAPTOR:	FD08/12
ANTENNA ADAPTOR:	FDA

IN-DASH INSTALLATION AREA DIMENSIONS				
	DEPTH	MAX DEPTH	WIDTH	HEIGHT
CAVITY	7 ³ / ₄ "	7 ³ / ₄ "	10 ¹ / ₂ "	4 ³ / ₈ "
DASH OPENING	TYPE: FORD DOUBLE DIN		7 ¹ / ₄ "	4 "
DASH MATERIAL: PLASTIC			THICKNESS: 1 ¹ / ₈ "	
FOR MAX DEPTH		<input type="checkbox"/> REMOVE REAR SUPPORT <input type="checkbox"/> MODIFY CAVITY		

AMPLIFIER/EQ MOUNTING LOCATIONS (WxHxD)			
UNDER/IN DASH	UNDER SEAT	GLOVE BOX	TRUNK/CARGO
			Various

Dimensions shown are inches.
For inch/mm conversions refer to chart section.

NOTE: THIS MANUAL IS BASED ON CAREFULLY DOCUMENTED RESEARCH. ABSOLUTE ACCURACY IS ATTEMPTED BUT NOT GUARANTEED. USE THIS MANUAL AS A REFERENCE GUIDE. SCOSCHE, INC. CANNOT BE RESPONSIBLE FOR INCONSISTENCIES THAT MAY OCCUR.



- B = BACK UP PLATES REQUIRED.
- C¹ = CUT TRIM/PLASTIC (STRUCTURE).
- C² = CUT STEEL.
- D = BELOW DECK ONLY.
- D¹ = LIFT PORTION OF DECK. (MAY REQUIRE STRUCTURAL REINFORCEMENT).
- D² = CUT STEEL WHEN TOP MOUNTED. DO NOT IF BELOW DECK.
- D³ = NARROW SURFACE, BELOW DECK ONLY.
- F¹ = MINIMUM MODIFICATION FILE SHAFT HOLES OR DASH OPENING.
- F² = MODIFY DASH CAVITY AND/OR PANEL.
- K = INSTALLATION KIT, SPACER OR ADAPTOR REQUIRED.
- K¹ = KIT MODIFICATIONS REQUIRED.
- K² = EXTENSION KIT RECOMMENDED.
- K³ = WHEN EQUIPPED WITH FACTORY "ELECTRONIC" RADIO.
- K⁴ = FABRICATE PANEL/BRAKETS.


UPDATED
THROUGH
'97 ☐
'98 ☐
'99 ☐
'2000 ☐

MERCURY 1996-UP MOUNTAINEER

Sport Utility, 4 Door
JBL Sound/Premium Sound

FRONT DOORS


Factory Provisions: Ford 6 x 8" mounted in factory adaptor.
Aftermarket: 5 $\frac{1}{4}$ "K, 6 $\frac{1}{2}$ "K, 5 x 7"K, 6 x 8"
K=SA68



ADAPTER CAVITY W H D
7 $\frac{11}{16}$ " x 5 $\frac{5}{16}$ " x 2 $\frac{1}{2}$ "

REAR DOOR - 4 DOOR


Factory Provisions: 6 x 8" JBL in factory adaptor.
Aftermarket: 5 $\frac{1}{4}$ "K, 6 $\frac{1}{2}$ "K, 5 x 7"K, 6 x 8"
K=SA68



ADAPTER CAVITY W H D
5 $\frac{5}{16}$ " x 7 $\frac{11}{16}$ " x 2 $\frac{1}{2}$ "

REAR SIDE PANELS:

Factory Provisions: 8" JBL subwoofer in enclosure
Aftermarket: 8" sub, C¹, C², K



Factory amplifiers are located behind rear cargo area side panel, see factory amplifier access.

- K⁵ = WHEN EQUIPPED WITH STANDARD TWO SHAFT RADIO/TAPE PLAYER. FABRICATE KIT WHEN EQUIPPED WITH FLAT FACE ELECTRONIC RADIO/TAPE PLAYER.
- K^S = SCOSCHE KIT RECOMMENDED.
- N = NOT RECOMMENDED. EXTENSIVE MODIFICATION REQUIRED.
- P = PERFECT WITHOUT MODIFICATION.
- P¹ = MODIFY OR REMOVE POCKETS.
- P² = COIN POCKET LOCATION IN DASH (MAY REQUIRE TRIM KIT).
- P³ = PERFECT WHEN EQUIPPED WITH STANDARD TWO SHAFT RADIO, K WITHOUT.
- R = REAR LOAD ISOMOUNT.
- U = UNDERDASH.
- W¹ = WITH POWER WINDOWS ONLY.
- W² = WITHOUT POWER WINDOWS ONLY.

1996-UP MERCURY MOUNTAINEER

SPORT UTILITY, 4 DOOR, JBL SOUND/PREMIUM SOUND



DASH.

PRELIMINARY: DISCONNECT THE NEGATIVE BATTERY CABLE.

ANTENNA: THE FACTORY ANTENNA IS LOCATED ON THE TOP OF THE RIGHT FRONT FENDER.

RADIO REMOVAL AND IN-DASH INSTALLATION:

NOTE: THE FACTORY RADIO PROVISION IS FOR A FORD DOUBLE DIN STYLE RADIO. AN INSTALLATION KIT IS NECESSARY WHEN USING AN AFTERMARKET RADIO. WE RECOMMEND THE USE OF A SCOSCHE FD1300 KIT.

1. USING THE FORD DIN REMOVAL TOOL CAREFULLY INSERT THEM INTO THE HOLES ON THE OUTSIDE EDGES OF THE RADIO TO RELEASE THE RADIO AND PULL IT OUT OF THE DASH CAVITY.
2. UNPLUG ALL CONNECTORS AND REMOVE THE RADIO.

FORD-JBL SOUND:

FACTORY AMPLIFIER, FACTORY SUBWOOFER/ENCLOSURE ACCESS:

NOTE: THE FACTORY AMPLIFIERS (4 CH / JBL SUB) AND 8" SUBWOOFER/ENCLOSURE ARE LOCATED BEHIND THE REAR RIGHT CARGO AREA SIDE PANEL.

1. REMOVE (3) SCREWS FROM LOWER PANEL EDGE UNDER CARPET IN THE REAR CARGO AREA.
2. REMOVE REAR SHOULDER SEAT BELT SWIVEL POINT (T-45 TORX BOLT). ON 2-DOOR EXPLORER REMOVE FRONT SHOULDER AND FRONT FLOOR SEAT BELT POINTS ALSO. (T-45 TORX BOLT)
3. REMOVE (8) PANEL FASTENERS FROM PANEL USING A PANEL REMOVAL TOOL.
4. POP UP REAR TAILGATE SILL PLATE.
5. EXTRACT (1) SCREW FROM COAT HANGER HOOK.
6. REMOVE REAR SIDE PANEL.

FRONT DOOR SPEAKER INSTALLATION:

NOTE: THE FACTORY SPEAKER PROVISION IS FOR A 6 X 8" MID/TWEETER ENCLOSURE IN A FACTORY ADAPTOR.


1. EXTRACT (2) SCREWS FROM UNDER THE DOOR PULL HANDLE.
2. UNSNAP DOOR RELEASE PLASTIC TRIM CUP.
3. USE A PANEL REMOVAL TOOL TO CAREFULLY PRY OUT ON THE EDGES OF THE DOOR PANEL TO RELEASE THE PANEL CLIPS.
4. RELEASE CLIPS HOLDING THE POWER WINDOW SWITCH PANEL, UNPLUG AND REMOVE.
5. LIFT PANEL UP AND AWAY FROM DOOR TO REMOVE.
6. EXTRACT THE (4) SCREWS SECURING THE SPEAKER TO THE ADAPTOR, PULL THE ENCLOSURE FROM THE CAVITY, UNPLUG THE LEADS AND REMOVE.

4-DOOR EXPLORER


REAR DOOR SPEAKER INSTALLATION:

NOTE: THE FACTORY SPEAKER PROVISION IS FOR A 6 X 8" SPEAKER MOUNTED IN A FACTORY ADAPTOR.

1. EXTRACT (2) SCREWS FROM UNDER THE DOOR PULL HANDLE.
2. UNSNAP DOOR RELEASE PLASTIC TRIM CUP.
3. USE A PANEL REMOVAL TOOL TO CAREFULLY PRY OUT ON THE EDGES OF THE DOOR PANEL TO RELEASE THE PANEL CLIPS.
4. RELEASE CLIPS HOLDING THE POWER WINDOW SWITCH PANEL, UNPLUG AND REMOVE.
5. LIFT PANEL UP AND AWAY FROM DOOR TO REMOVE.
6. EXTRACT THE (4) SCREWS SECURING THE SPEAKER TO THE ADAPTOR, PULL THE ENCLOSURE FROM THE CAVITY, UNPLUG THE LEADS AND REMOVE.



FRONT DOOR 6 x 8" PROVISION.



FORD 8 PIN POWER AND 16 PIN AUDIO CONNECTORS.



REAR SIDE PANEL FACTORY AMP LOCATION.