


LPAI25

STEREO REPLACEMENT & STEERING WHEEL CONTROL INTERFACE FOR 2002-15 AUDI STEREOS

This LPAI25 allows you to replace your factory OEM stereo while retaining factory steering wheel controls, OEM phone buttons and full amplified systems if vehicle is equipped



DESIGNED & ENGINEERED IN U.K CUSTOM MANUFACTURED IN CHINA

APPLICATION GUIDE

AUDI

2006-12 A3 **2002-15** A4 **2004-11** A6 **2007-13** TT (MK2 Model, Excluding Vehicles w/ Digital Amplifier)

For Vehicles with Quadlock connnector (40 Pin) and ISO connector (36 Pin)

FEATURES

RETAINS:

- Steering Wheel Controls (if equipped)
- OEM Phone Buttons (if aftermarket head unit supports)
- Maintains Full Bose Amplified Systems [If equipped (w/ LP4EUAR Sold Separately)]*



LP4EUAR (Sold Separately)

LIABILITY DISCLAIMER

This LPAI25 instruction manual is based on carefully documented data and research. Scosche Industries Inc. cannot be held responsible for discrepancies/inconsistencies that may occur due to the vehicle manufacturing changes or options, or damages that may occur in the vehicle during the installation of components while using this manual.

If you have any further questions, call our toll-free technical help line at: 1-800-363-4490 x1

© Scosche Industries, Inc 2018

LAI10 02/18

WIRING COLOR CODES

White=
White/Black=
Green=
Green/Black=
Black=
Yellow=
Red=
Blue=

Left Front Positive (LF+) Left Front Negative (LF-) Left Rear Positive (LR+) Left Rear Negative (LR-) Chassis Ground +12V Constant Power +12V Accessory +12V Power Antenna (Remote Out)


Gray= Gray/Black= Violet= Violet/Black= Orange= Right Front Positive (RF+) Right Front Negative (RF-) Right Rear Positive (RR+) Right Rear Negative (RR-) Illumination

NAVIGATION CONNECTIONS:

Pink=	(VSS) Vehicle Speed Pulse Signal		
Lt. Green=	Parking Brake trigger (-12V when park brake ON)		
Purple/White=	Reverse Signal		
Blue=	Amp Remote		
Blue/Black=	Remote Output		

NOTE: The **RED** accessory output wire from the LPAI25 interface is rated at 10A Max output for most after-market head units. We do NOT recommend connecting additional +12A switched accessories to this output source as that may cause damage to the LPAI25 module itself. If 10A output is not sufficient, then a relay is needed. (Relay not included)

STEERING WHEEL WIRING CODES



- 1. Prepare SWC steering wheel connector harness by using the chart below
- 2. Connect the harness to the interface module.
- For Alpine, Clarion, JVC, Panasonic and Sony car stereos, connect the 3.5mm male steering plug into the steering wheel input jack at the back of the stereo.
- For Kenwood and newer JVC stereos, connect the BROWN wire from the steering wheel harness to the "Remote in" wire at the back of the stereo.

STEREO BRAND	CONFIGURATION	CONNECTION TO STEREO
ALIPNE	Cut Green Loop	3.5mm
CLARION	Cut Violet Loop	3.5mm
JVC	Cut Green & Violet Loop	3.5mm or Brown (Key1)
KENWOOD	Cut Orange & Green	Brown (Key 1)
PANASONIC	Cut Orange	Brown (Key 1)
PIONEER / SONY	Do Not Cut Loops	3.5mm
OTHER BRANDS	Call Tech Support	Brown, Gray, Black



If you have any questions or need technical assistance with the installation, or the most current application please call or visit us on the web at:

SUPPORT = (800) 363-4490 x1 | www.scosche.com/contact


Continued on Page 3

SWC WIRING HARNESS


Kenwood Sample 2

NOTE: Cut wire only, do NOT remove


Orange Culton



Pioneer / Sony Sample 3 NOTE: Do NOT cut or remove wires



STEERING WHEEL CONTROLS



*Vehicle icon may vary

Detach this page for customer use

If you have any further questions, call our toll-free technical help line at: 1-800-363-4490 x1

LPAI25 WIRING DIAGRAM

