


STEREO REPLACEMENT & STEERING WHEEL CONTROL INTERFACE FOR SELECT 1995-08 BMW/MINI STEREOS w/i-BUS Data Systems

This LBW10 allows you to replace your factory OEM stereo while retaining factory steering wheel controls if vehicle is equipped.

(NOT for use with amplified systems)



DESIGNED & ENGINEERED IN U.K
CUSTOM MANUFACTURED IN CHINA

APPLICATION GUIDE

BMW:

1998-06 3-SERIES (E46)
1997-00 5-SERIES (E39)
1995-01 7-SERIES (E38)
2000-01 X5 (E53)
2002-08 Z4 (E85)

MINI

2001-06 MINI COOPER (I-BUS)

FEATURES

RETAINS:

- **Steering Wheel Controls** (if equipped)
- **OEM Phone Buttons** (if equipped)

NOTES:

- Safe for OEM Diagnostic equipment
- Business Model Head Unit w/ 17-Pin Connector
- For **non**-amplified systems

LIABILITY DISCLAIMER

This LBW10 instruction manual is based on carefully documented data and research. Scosche Industries Inc. cannot be held responsible for discrepancies/inconsistencies that may occur due to the vehicle manufacturing changes or options, or damages that may occur in the vehicle during the installation of components while using this manual.

If you have any further questions, call our toll-free technical help line at: 1-800-363-4490 x1

WIRING COLOR CODES

White=	Left Front Positive (LF+)	Gray=	Right Front Positive (RF+)
White/Black=	Left Front Negative (LF-)	Gray/Black=	Right Front Negative (RF-)
Green=	Left Rear Positive (LR+)	Violet=	Right Rear Positive (RR+)
Green/Black=	Left Rear Negative (LR-)	Violet/Black=	Right Rear Negative (RR-)
Black=	Chassis Ground	Orange=	Illumination
Yellow=	+12V Constant Power		
Red=	+12V Accessory		
Blue=	+12V Power Antenna (Remote Out)		


NAVIGATION CONNECTIONS:

N/A

Supplied with 17-way (round pin)

NOTE: The **RED** accessory output wire from the **LBW10** interface is rated at 10A Max output for most aftermarket head units. **We do NOT** recommend connecting additional +12A switched accessories to this output source as that may cause damage to the **LBW10** module itself. If 10A output is not sufficient, then a relay is needed. **(Relay not included)**

STEERING WHEEL WIRING CODES



1. Prepare SWC steering wheel connector harness by using the chart below
2. Connect the harness to the interface module.
3. For Alpine, Clarion, JVC, Panasonic and Sony car stereos, connect the 3.5mm male steering plug into the steering wheel input jack at the back of the stereo.
4. For Kenwood and newer JVC stereos, connect the **BROWN** wire from the steering wheel harness to the **"Remote in"** wire at the back of the stereo.

STEREO BRAND	CONFIGURATION	CONNECTION TO STEREO
ALIPNE	Cut Green Loop	3.5mm
CLARION	Cut Violet Loop	3.5mm
JVC	Cut Green & Violet Loop	3.5mm or Brown (Key1)
KENWOOD	Cut Orange & Green	Brown (Key 1)
PANASONIC	Cut Orange	Brown (Key 1)
PIONEER / SONY	Do Not Cut Loops	3.5mm
OTHER BRANDS	Call Tech Support	Brown, Gray, Black

**TECH
SUPPORT**



If you have any questions or need technical assistance with the installation, or the most current application please call or visit us on the web at:


(800) 363-4490 x1 | www.scosche.com/contact

SWC WIRING HARNESS

SWC Harness Sample Cuts

Use the SWC radio samples cuts illustrated as possible outcomes to your installation. Please note that the wire loops are only meant to be cut if necessary for your installation. Do NOT detach the loops from the connector, cut only. If you have any further questions, call or visit us on the web at:


1-800-363-4490 Ext.1 | www.scosche.com/contact



If you have any further questions, call our toll-free technical help line at:

1-800-363-4490 ext. 1

STEERING WHEEL CONTROLS



- 1. Volume +
- 2. Volume -
- 3. Track +

- 4. Track -
- 5. Short Press - Pick Up
Long Press - Hang Up

Detach this page for customer use

If you have any further questions, call our toll-free technical help line at: 1-800-363-4490 x1

LBW10 WIRING DIAGRAM

